

DISPLEX

INSTRUCTIONS FOR USE

1. Mask around the display with tape to separate the area to be polished from surrounding components / finishes.
2. Apply a small amount of Displex to the display. Polish the scratched areas vigorously for 2 – 3 minutes using a clean soft cotton cloth. Repeat the process on deep scratches.
3. For displays covered with a transparent film, the entire transparent part of the display must be polished until the film has been completely removed.

WARNING: Only for phone displays, plastic watch crystals, cockpit shields, and wood trim

CAUTION:

KEEP OUT OF THE REACH OF CHILDREN

AVOID CONTACT WITH EYES AND MOUTH

IN CASE OF CONTACT WITH EYES AND MOUTH FLUSH WITH PLENTY OF CLEAN WATER

IF SWALLOWED – DO NOT INDUCE VOMITING - CONTACT A PHYSICIAN IMMEDIATELY